

APPENDIX A

ANSWERS TO REVIEW QUESTIONS

Chapter 1 Laws Concerning Control of Wood-destroying Pests

- (1) False. Pest management professionals may use many other activities (prevention, habitat modification, etc.) besides pesticide application to control pests. These other practices increase the overall effectiveness of the control program.
- (2) B (3) B (4) D (5) C (6) A
- (7) False. Category 7B commercial applicators must consider the possibility that endangered or threatened species may be affected by pesticides applied in and around buildings.
- (8) C (9) D
- (10) Definition, general description, why pesticide is used, general toxicity information (i.e., compound type, where applied, exposure information, amount/rate applied, label compliance), precautionary measures, and instructions to customer on site preparation, precautions, etc.
- (11) True
- (12) False. Category 7B commercial applicators must consider air circulation patterns and ventilation systems when spraying inside buildings and must also consider the possibility of off-target drift when spraying outside of buildings.
- (13) D
- (14) Unless otherwise specified by the product label, applicators must wear long pants, protective footwear, long-sleeved clothing (short-sleeved allowed if wash water or waterless soap is immediately available), and gloves impervious to the pesticide.
- (15) False. According to Rule 13 of Regulation 637, such statements are prohibited.
- (16) Site evaluation, description, inspection, and monitoring; the concept of threshold levels; the relationship between pest biology and pest management methods; pest population reduction and pest prevention; development and implementation of an IPM program that reduces the possible impact of pesticides; evaluation of an IPM program to determine effectiveness; record-keeping requirements of an IPM program.
- (17) D

Chapter 2 The Biology of Termites and Other Wood-destroying Pests

- (1) A (2) B (3) B (4) E (5) C (6) A (7) A (8) D (9) B (10) C (11) C (12) A (13) D (14) B (15) B (16) C (17) A (18) C (19) C (20) E (21) C (22) A
- (23) Maintaining the proper levels of temperature and moisture is essential to the survival of the colony. Warm, moist conditions provide an ideal site for the growth of microorganisms, particularly fungi, which are a source of protein and vitamins essential to the termite. The accumulation of termite fecal material in the nest, in turn helps to promote the growth of fungi. The type of soil will also affect the ability of the subterranean termite to flourish. Sand is preferred over clay.
- (24) E (25) D (26) D (27) A (28) B (29) D (30) C (31) E (32) D (33) E (34) C (35) B (36) A (37) B (38) B (39) B

Chapter 3 Equipment and Methods

- (1) C (2) B (3) A (4) A (5) D (6) C (7) D
- (8) Because the smallest opening in the spray line determines the actual capacity for delivery, regardless of the size of the hose. If the diameter of the coupling is smaller than the diameter of the hose, it will decrease the delivery rate and the desired volume of spray will not be delivered.
- (9) B
- (10) Without accurate calibration of sprayers, the amount of pesticide delivered will be incorrect. Overdosage will contaminate the spray area or result in runoff. Less than the recommended dosage might fail to control the pest.
- (11) A flow meter and timer. It is measured as the amount of time it takes to deliver 1 gallon of liquid per unit area.
- (12) The type of soil that termiticides are being injected into—i.e., its composition, compaction, etc.; the method used to inject the insecticide; and the type of construction being treated.
- (13) A (14) D (15) C
- (16) The well's location from the foundation, the depth of the well, where the supply line enters the structure, and the depth to water.
- (17) True

- (18) Flashlight, steel tape, folding rule, rolling measuring device, penknife, etc. Wear coveralls, bump hat, and gloves for inspecting crawl spaces and other non-basement areas.
- (19) The presence of swarmers or their shed wings, live or dead termites, damaged wood, brown mudlike material lining galleries, mud tubes out in the open, or mudlike material covering cracks between boards and other areas.
- (20) Termites construct mud tubes so that they can travel from one feeding site to another in a protected environment (maintaining proper conditions of temperature and moisture). Single mud tubes out in the open are about the diameter of an ordinary lead pencil.
- (21) Termites remove only the soft layers (spring wood) within the annual rings of the wood grain, penetrating the hard layers only to get from one soft layer to another. This frequently leaves a damaged piece of wood looking very much like pages of a book. Also, they line their galleries with a brown, mudlike material in an irregular pattern.
- (22) D
- (23) An adequate diagram of the structure on cross-ruled paper accompanied by a description of the structure and the problems to be solved. The drawing should include the type of construction, all crosswalls, stairways, doorways, porches, stoops, and other parts of the structure that will affect the method of treatment. It must be drawn to scale, revealing blind areas that are often sites of severe infestation. Every place where live termites are found should be indicated on the diagram. All existing damage, inaccessible areas, and other unusual situations should be indicated. All details of construction, including:
- The materials of which the outside walls and foundations are made (e.g., concrete block, stone, etc.) and whether the foundation extends below grade.
 - The places where it will be necessary to drill through the concrete floor, such as in doorways, and driveways.
 - Whether the building has a basement or a crawl space or is a concrete slab on grade.
 - The locations where ventilators should be installed.
 - The conditions that may be conducive to termite attack (such as improper grade).
 - Other pertinent information.
- (24) 1) Sanitation of the building site, 2) structural and construction defects, and 3) barriers (mechanical or chemical).
- (25) Remove all tree roots and stumps from the building site before starting construction. Remove spreader boards and grade stakes before concrete sets. Remove form boards and wood scraps from soil before filling or backfilling.
- Do not bury wood in the backfill, under porches, or under steps—this may attract termites.
- (26) D (27) A (28) True (29) B (30) D (31) C
- (32) False. Soil treatment should be used as a supplement to good construction, not as a substitute for it.
- (33) Treatment of the entire soil surface under any area to be covered with concrete, including garage and basement floors, entrance platforms, and filled porches.
Treatment with additional amounts of chemical to the soil beneath those areas that lie adjacent to foundation walls, beneath interior walls, around sewer and utility openings and at other possible points of entry.
Treatment of footings and backfill outside foundation walls and inside walled areas where there is a crawl space. Accessible areas such as these could be treated later, but it's easier to do it at construction time.
Treatment of empty spaces or voids in concrete blocks.
- (34) A (35) True (36) B (37) D (38) D (39) E
(40) C (41) A (42) A (43) A
(44) B (45) C (46) D (47) F
- (48) Momentary immersion by bulk dipping, pressure, or combination pressure/diffusion treatment, treatment of composite boards and laminated products by treatment of the wood finish, hot and cold dip treatments and long soaking periods, spray or brush-on treatments with borate slurries or pastes, and placement of fused borate rods in holes drilled in wood already in use.
- (49) A (50) C
- (51) Foams penetrate into hard-to-reach cavities and voids and improve termiticide distribution in soils. Liquid termiticide is combined with air to create uniform, small-diameter bubbles. The foam carries the liquid termiticide in the spaces between the bubbles. As the foam breaks down, it leaves a thin residue on the surfaces it had contact with. The fact that foam is less dense than liquid enables it to dispense uniformly. The foaming agent delays collapse of the bubbles providing more time for the insecticide to reach desired areas. **Surfactants** in the foam improve penetration of the chemical into the soil; thus, a more uniform and continuous residual barrier is established.
- (52) C (53) E (54) C (55) B (56) A (57) C
- (58) They must be non-repellent, slow acting, and readily consumed by termites.
- (59) The toxic material in the bait must kill slowly enough to allow foraging termites to return to the colony and spread the bait through food sharing (trophallaxis). Other factors include dose dependency, learned avoidance (e.g., dead termites accumulating around the toxic material and repelling other termites from feeding), suitable temperature and moisture, and early detection.

- (60) A (61) B
- (62) Bait placement and number depend on the product used, the characteristics of the site, and the amount of termite activity.
- (63) Often placed every 10 to 20 feet around the perimeter of the building 2 feet out from the foundation.
- (64) Aboveground bait systems are placed in the path of the termites (in mud tubes or in areas of wood damage and termite presence), so that the termites come in direct contact with the bait. More immediate colony elimination can be obtained than by placing baits in the soil around the structure.
- (65) D (66) D
- (67) Baits fit well into an IPM program as an addition to existing termite control methods such as eliminating conditions conducive to termite infestation, judicious use of liquid soil products as a spot or limited barrier application, and use of wood treatment products.
- (21) The main problem areas are limited to the openings for pipes, plumbing, soil lines, etc., any faults or cracks in the slab, and any grading stakes or embedded articles that termites might use to gain access through the slab.
- (22) When there is a veneer of brick, stone, or stucco that extends below grade.
- (23) B (24) A
- (25) False. No routine treatment of wood is done in monolithic slab construction. Wood treatment is done only when there is a specific reason for doing so.
- (26) C
- (27) Dig a trench 6 to 8 inches wide and a few inches deep next to the walls or piers, taking care not to go below the top of the footing. If the land slopes or if the footing is more than 12 inches deep, make crowbar, pipe, or rod holes about 1 inch in diameter and a foot a part in the bottom of the trench. The holes should go to the footing—this will help distribute the chemical evenly along the wall.

Chapter 4 Soil Treatment for Subterranean Termites


- (1) B (2) D (3) C (4) A (5) B (6) C (7) B
- (8) Rodding is the injection of termiticide into the soil through a long pipe inserted at appropriate intervals so that insecticide can be carried to the level of the footing. Trenching is removing soil to with in about 1 foot above the footing and treating the soil with insecticide as it is replaced. The soil is saturated with chemical to the top of the footing.
- (9) C (10) True (11) A (12) D (13) A (14) C
- (15) When floor covering, plumbing (bathtubs, sinks, showers), cabinets, or other furnishings obstruct access to drilling from the inside.
- (16) A (17) A
- (18) It has the added advantage over short rodding of possible access behind concrete porches. A disadvantage is that long rodding for any significant distance may leave untreated areas because the rod may veer away from the foundation down into the soil.
- (19) Termites may come from (1) the subslab area, (2) up through the expansion joint at the edge of the slab, and (3) up through a crack in the floor beneath a wood partition. A fourth possible termite entry point would be through concrete block voids.
- (20) A sharp bit and steady pressure are required when drilling terrazzo to prevent chipping around the edge of the drill hole. One method is to apply light pressure on the drill while quickly hitting and releasing the trigger. This prevents the bit from jumping about and damaging the surface of the floor. Terrazzo may be patched by saving the drilling dust so that a portion of the dust can be mixed with cement and made to match the original floor. If this method is not acceptable to the property owner, a professional terrazzo floor company can be contacted to patch the drill holes.
- (28) Make a trench along the exterior foundation wall 6 to 8 inches wide and about a foot deep. If needed, holes can be made in the trench bottom the same as for the trench along the interior wall.
- (29) B
- (30) It is necessary to treat the soil to a greater depth than is required for other types of houses. The trench is prepared in the same way, but the pipe or rod holes should extend down to the top of the footing to aid in proper distribution of the chemical to all parts of the wall.
- (31) Where the termites are coming from beneath the concrete floor in the basement, remove any wood that may extend into the ground, treat the soil, and then seal cracks or holes with a dense cement mortar. When the infestation is located between the floor and wall (expansion joint) or around a furnace, make a series of holes, spaced about 1 foot apart, through which a chemical can be poured or injected. Holes along a wall should be made about 6 to 8 inches from it so as to clear the footing and reach the soil beneath.
- (32) Termiticide may seep into and contaminate the structure.
- (33) A

Solutions for Example 1: Pier and Beam Foundation

Foundation wall is 1 foot thick.

Piers are 3 feet in circumference.

Depth from grade to footing is 2 feet for piers and foundation wall.



34. How many linear feet are there in the structure above?

exterior: 20 ft.+20 ft.+10 ft.+10 ft.+30 ft.+30 ft.+60 ft.+60 ft. =240 ft.

interior: 18 ft.+20 ft.+10 ft.+10 ft.+30 ft.+28 ft.+58 ft.+58 ft. = 232 ft.

piers: 15 x 3 ft. = 45 ft.

240 linear ft. exterior of foundation wall + 232 linear ft. interior of foundation wall +45 ft. (15 piers x 3 linear ft.) = 517 linear feet

35. How many gallons of spray mix would be needed to treat the linear feet in this structure using the standard rate of mixture (4 gal./10 linear ft./ft. of depth) for vertical treatment?

$$\frac{517 \text{ linear ft.} \times 2 \text{ ft. of depth} \times 4 \text{ gal.}}{10 \text{ linear ft./ft. of depth}} = 413.6 \text{ gallons}$$

36. How many gallons of "Termite-Icide" would be needed to treat the linear feet at the 0.5 percent rate?

$$\frac{1.25 \text{ gal. "Termite-Icide"} \times X \text{ gal. "Termite-Icide"}}{96 \text{ gal. spray mix}} = \frac{413.6 \text{ gal. spray mix}}{96}$$

$$\frac{517}{96} = 5.38 \text{ gallons "Termite-Icide"}$$

37. How many square feet are within the foundation wall of the drawing above?


$$\text{Section A (18 ft.} \times \text{58 ft.)} + \text{Section B (10 ft.} \times \text{10 ft.)} + \text{Section C (40 ft.} \times \text{28 ft.)} = 1,044 \text{ sq. ft.} + 100 \text{ sq. ft.} + 1120 \text{ sq. ft.} = 2,264 \text{ sq. ft.}$$

38. How many gallons of spray mix would be needed to treat the horizontal surface (square feet) using the standard volume for a 0.5 percent rate if the substrate is fill sand?

$$\frac{2,264 \text{ sq. ft.} \times 1 \text{ gal.}}{10 \text{ sq. ft./gal}} = 226.4 \text{ gallons}$$

Solutions for Example 2: Monolithic Slab

Monolithic slab with 1 foot from grade to bottom of perimeter beam



39. How many square feet are in the monolithic slab surface?

$$\text{Section A (30 ft.} \times \text{55 ft.)} + \text{Section B (10 ft.} \times \text{25 ft.)} = 1,900 \text{ sq. ft. [or Section A1 (30} \times \text{30)} + \text{Section B1 (40} \times \text{25)]}$$

40. How many linear feet would be treated for a perimeter treatment?

$$30 \text{ ft.} + 30 \text{ ft.} + 10 \text{ ft.} + 25 \text{ ft.} + 40 \text{ ft.} + 55 \text{ ft.} = 190 \text{ ft.}$$

41. If "Termite-Icide" costs \$97 for a 2.5-gallon jug, how much will the chemical cost to treat the horizontal surface of the monolithic slab at the 0.5 percent rate?

$$\frac{\$97}{2.5 \text{ gal. concentrate}} \times 1.25 \text{ gal. concentrate} / 96 \text{ gal. solution} \times 1 \text{ gal. solution} / 10 \text{ sq. ft.} \times 1,900 \text{ sq. ft.} = \$95.99$$

42. How much would it cost to treat the perimeter at the 0.5 percent rate?

$$\begin{aligned} & \$97/2.5 \text{ gal. concentrate} \times 1.25 \text{ gal. concentrate}/ \\ & 96 \text{ gal. solution} \times 4 \text{ gal. solution}/10 \text{ linear ft.} \\ & \times 190 \text{ linear ft.} = \$38.40 \end{aligned}$$


Solutions for Example 3: Monolithic Slab with a Patio

Depth from soil grade to bottom of slab is 2 feet.

Bath trap is 2 square feet.

7 pipe penetrations are less than 6 inches in diameter.

1 pipe penetration is 8 inches in diameter.



43. Using the label instructions, how many holes would be drilled in the slab to treat cracks, seam, and pipe penetrations in the drawing above?

$$\begin{aligned} 16 \text{ ft. of crack} &= 16 \text{ holes} \\ 15 \text{ ft. seam} &= 15 \text{ holes} \\ 7 < 6\text{-inch pipe} &= 7 \text{ holes} \\ 1 \text{ 8-inch pipe} &= 2 \text{ holes} \\ \text{Total} &= 40 \text{ holes} \end{aligned}$$

44. How many gallons of 0.5 percent emulsion would be required to treat the cracks, seam, pipe penetrations, and bath trap?

$$\begin{aligned} 31 \text{ ft. cracks \& seams} \times 4 \text{ gal./10 linear ft.} &= 3.1 \times 4 \text{ gal.} = 12.4 \text{ gal.} \\ 7 < 6\text{-inch pipe} &= 7 \times 1.5 \text{ gal.} = 10.5 \text{ gal.} \\ 1 \text{ 8-inch pipe} &= 2 \times 1.5 \text{ gal.} = 3.0 \text{ gal.} \\ 2 \text{ sq. ft. bath trap} \times 3 \text{ gal./sq. ft.} &= \underline{6.0 \text{ gal.}} \\ \text{Total} &= 31.9 \text{ gal.} \end{aligned}$$

45. How many gallons of emulsion would be needed to treat the building perimeter?

$$\begin{aligned} 40 \text{ ft.} + 35 \text{ ft.} + 15 \text{ ft.} + 15 \text{ ft.} + 25 \text{ ft.} + 20 \text{ ft.} &= 150 \text{ linear ft.} \\ 150 \text{ linear ft.} \times 4 \text{ gal./10 linear ft.} &= 60 \times 2 \text{ ft. of depth} = 120 \text{ gallons} \end{aligned}$$

Chapter 5 Other Treatments for Subterranean Termites

- (1) B (2) A (3) D (4) C
- (5) Close off all vents, turn on the fan for the air system, and check each hole for air flow. If air flow is detected, plug the holes and do not treat them.
- (6) Any termiticide deposits in ducts must be cleaned out. An industrial wet vac is usually the best method to get liquid material out of the ducts. Charcoal filters should be used over heat registers. Check and follow the termiticide label for instructions on chemical deactivation. Contact the termiticide manufacturer for up-to-date information.
- (7) D
- (8) Cut the wooden members at least 4 inches above floor level, then remove the portion that extends through the floor. The soil underneath should be thoroughly treated with termiticide, and then concrete poured into the hole and into a form extending to the remaining portion of the wooden members for support.
- (9) C
- (10) Ideally, wooden sills should be replaced with concrete. If not, walls and voids in wooden sills should be treated with termiticide, starting as close as possible beneath the window to ensure thorough coverage. The ground outside the window should also be treated.
- (11) D (12) B
- (13) Wooden porches with outside ground contact should have all wood cut off above ground level and supporting concrete placed under it.
- (14) Sometimes termiticide will leak through hollow block, tile, and rubble foundations, or vapor will escape from the uncapped tops of hollow blocks, causing residue problems. To prevent this, make sure all cracks and openings are sealed. If the mortar joints of rubble walls are in poor condition, the wall should be sealed with concrete.
- (15) D (16) C (17) B
- (18) The outside foam should be removed to 6 inches above and below the grade level to allow for proper treatment and future inspection. Control may be achieved by trenching and treating soil and backfill where insulation board has been removed to below grade. This will create a soil barrier that interrupts termite access through the insulation.
- (19) True (20) A (21) C (22) A

Chapter 6 Other Wood-destroying Insects

- (1) C
- (2) Inspect wood prior to purchase. Use properly kiln- or air-dried wood. Seal wood surfaces. Use chemically treated wood. Ensure good building design.
- (3) True
- (4) Use good building design and practices such as proper ventilation, drainage, and clearance between wood and soil to reduce the moisture content of wood in a structure. Central heating and cooling systems also speed up the wood drying process.
- (5) B (6) A (7) D (8) C (9) C (10) A (11) B (12) D (13) A (14) A (15) B (16) C
- (17) C (18) C (19) B
- (20) "Shot-hole" exit holes in unfinished wood about the size of a pencil lead (powder sifts from holes), frass (fresh frass from active infestations is the color of newly sawed wood), larvae, or adults (live insects indicate active infestation).
- (21) False. All exposed surfaces of wood (painted and unpainted) should be examined.
- (22) True (23) B (24) C (25) A (26) True
- (27) Oil solutions present a possible fire hazard, greater expense, greater hazard and discomfort to the applicator, and danger of damaging plants near the treatment area.
- (28) True
- (29) To be certain it will not damage the finish, apply only a small amount of an oil-based solution to an out-of-the-way area and allow it to dry before making a complete treatment. Insecticide should be applied to the entire surface of the infested wood using a flat-fan nozzle at low pressure or a soft-bristled paintbrush. If there are only scattered patches of infestation, treat only the infested boards. Avoid overtreatment (i.e., if the solution runs off or puddles), particularly on hardwood floors laid over asphalt paper or asphalt-based mastic. The asphalt will be dissolved by excess oil and may bleed through the finished floor. Any excess solution should be wiped up immediately. Be careful not to mar the surface if the spray has temporarily softened the finish. An oil carrier may have a solvent action on some wood finishes. Therefore, keep all objects off treated areas for about 24 hours or until all stickiness has disappeared.
- (30) B (31) D (32) True (33) A (34) A (35) A, A, B, A, B, B, B, A (36) E
- (37) Improper attachment of wooden additions, dormers, and hollow wooden columns that absorb moisture. Patios or porch floors, door sills, downspouts, or grading where water collects or drains toward the structure. Regular gutter overflow pouring rainwater down the side of the building as well as back onto roof boards, fascia, soffits, etc. Leaking roof valleys. Improper

flashing around chimneys, vents, and skylights. Improper roofing or holes in the roof. Window sills directly exposed to rain. Lack of ventilation in any area where moisture accumulates. Inside moisture accumulates: around any leaking plumbing or drains (especially shower drains), in unvented attics and crawl spaces, in areas with unvented dishwashers, washing machines, icemakers, etc.

- (38) A (39) D
- (40) Dust tunnels or inject with pressurized liquid insecticide. Insert a dusted plug of steel wool or copper gauze in the tunnel. Fill the opening with caulk, wood filler, or a wooden dowel. A dusted plug stops new adults that otherwise would emerge through shallow caulking.

Chapter 7 Wood-damaging Fungi

- (1) Wood-destroying (decay fungi) and wood-staining (sapstaining fungi, molds).
- (2) D (3) D (4) C (5) D (6) C (7) A (8) A (9) B (10) A (11) B (12) C
- (13) A (14) A (15) A (16) C
- (17) False. The wood must have some moisture in it to decay. Dry rot fungi can infest relatively dry wood because of water-conducting strands that can carry water from damp soil to wood.
- (18) B (19) A (20) A (21) B (22) C (23) B (24) A (25) B (26) D
- (27) Chemical stains occur in logs or in lumber during seasoning. These can be prevented by rapid air drying or by using relatively low temperatures during kiln drying.
- (28) Termites bring moisture and soil up into wood from the subsurface colonies. They feed on wood or around the outside of wood to form their enclosed runways. The warm, moist conditions that prevail within the termite nest also support the growth of fungi, which provide a source of protein and vitamins essential to the termite. The accumulation of termite fecal material in the nest helps to promote the growth of the fungi.
- (29) True (30) A
- (31) A sharp-pointed object such as an icepick is used to poke into and pry up a segment of wood, especially in "latewood" areas of darker rings. In decayed wood, the pried-up section will break abruptly directly over the tool, whereas in sound wood the break will occur at a point away from the tool. The pick test will indicate the presence of wood decay at as little as 5 to 10 percent loss of weight.
- (32) Whether wood has a moisture content (20 percent or above) that will lead to decay, small changes in the moisture content of wood to demonstrate the success of a moisture control program over time, the likelihood of infestation or reinfestation by wood-boring insects, and

whether fungi seen on the wood surface are still actively growing.

- (33) The wood species involved, moisture distribution, grain direction, chemicals in the wood, weather conditions, and temperature.
- (34) Any five of the following:
- Water vapors from the combustion of natural gas that improperly vent into the attic or other enclosed areas.
 - Condensation on windows flowing down onto and into sills
 - Moisture from crawl spaces and the dirt below (up to 100 pounds/day/1,000 square feet).
 - Absent or improperly placed drain pipes, drain-spouts, etc.
 - Leaking roofs.
 - Poor side wall construction.
 - Improperly sealed foundations, basement walls.
 - Direct contact of wood with soil or concrete, allowing wicking action to pull water into wood.
 - Improper drainage of water away from structure or out of crawl spaces.
 - Improperly fitted flashing at roof lines or shingles with improper overhang.
 - Improper moisture barriers under stucco, shingles.
 - Sweating water pipes.
 - Improper exterior grade that allows water to drain toward the structure and remain in contact with it.
 - Dripping air conditioners or swamp coolers.
 - Leaking plumbing, appliances, toilets, shower stall pans.
 - Improper seals or caulk around bathtubs and showers.

Lack of vents or windows in bathrooms that allows moisture from baths and showers to accumulate.

Plugged or leaking downspouts from roof gutters.

- (35) False. More airtight buildings have increased water condensation and moisture problems.
- (36) True
- (37) Proper grading, roof overhangs, the use of gutters, downspouts, and drain tile.
- (38) A (39) B
- (40) To cause moisture to condense on the barrier and return to the soil rather than condensing on the floor and joists above in the subareas of buildings.
- (41) False. Some area of the soil surface should be left uncovered to allow wood in the crawl space to dry slowly.
- (42) B
- (43) Wear rubber gloves and long-sleeved clothing and wash thoroughly after handling. Never dispose of preservative-treated wood by domestic incineration or use as a fuel in fireplaces or wood-burning stoves.
- (44) False. Only by eliminating the moisture source can wood decay be completely controlled.
- (45) Borates are low hazard, easy to apply, long lasting, and quite effective. They are easy to mix in a water carrier and are available in a variety of formulations that allow spraying, brush-on, gel, and foam applications. For wood with a high moisture content that cannot be easily dried, a formulation is available that consists of solid rods that are inserted into holes drilled into the wood.

APPENDIX B

GLOSSARY

Glossary of Terms for Management of Wood-destroying Pests

ABSORPTION—The movement of a chemical into plants, animals (including humans), and/or microorganisms.

ACTIVE INGREDIENT—The chemical or chemicals in a pesticide responsible for killing, poisoning, or repelling the pest. Listed separately in the ingredient statement.

ACUTE TOXICITY—The capacity of a pesticide to cause injury within 24 hours following exposure. LD₅₀ and LC₅₀ are common indicators of the degree of acute toxicity. (See also *chronic toxicity*.)

ADJUVANT—A substance added to a pesticide to improve its effectiveness or safety. Same as additive. Examples: penetrants, spreader-stickers, and wetting agents.

ADSORPTION—The process by which chemicals are held or bound to a surface by physical or chemical attraction. Clay and high organic soils tend to adsorb pesticides.

AEROSOL—A material stored in a container under pressure. Fine droplets are produced when the material dissolved in a liquid carrier is released into the air from the pressurized container.

ALATES—The winged primary reproductives (both male and female) of the termite colony (alate=winged). (See also *swarmers*.)

ANTI-SIPHONING DEVICE—A device attached to the filling hose that prevents backflow or *back-siphoning* from a spray tank into a water source.

ANTIDOTE—A treatment used to counteract the effects of pesticide poisoning or some other poison in the body.

ATTRACTANT—A substance or device that will lure pests to a trap or poison bait.

BACK-SIPHONING—The movement of liquid pesticide mixture back through the filling hose and into the water source.

BACTERIA—Microscopic organisms, some of which are capable of producing diseases in plants and animals. Others are beneficial.

BAIT—A food or other substance used to attract a pest to a pesticide or to a trap.

BARRIER APPLICATION—Application of a pesticide in a strip alongside or around a structure, a portion of a structure, or any object.

BIOLOGICAL CONTROL—Control of pests using predators, parasites, and and/or disease-causing organisms. May be naturally occurring or introduced.

BIOMAGNIFICATION—The process whereby one organism accumulates chemical residues in higher concentrations from organisms it consumes.

BRAND NAME—The name or designation of a specific pesticide product or device made by a manufacturer or formulator; a marketing name.

BRICK VENEER—A facing of brick laid against and fastened to *sheathing* of a frame wall or tile wall construction.

BUDDING—Another means (other than *swarming*) for termites to form a new colony. Budding occurs when a number of individuals, including one or more wingless secondary reproductives, leaves a well established colony to start a new one.

CALIBRATE, CALIBRATION OF EQUIPMENT, OR APPLICATION METHOD—The measurement of dispersal or output and adjustments made to control the rate of dispersal of pesticides.

CARBAMATES (N-methyl carbamates)—A group of pesticides containing nitrogen, formulated as insecticides, fungicides, and herbicides. The N-methyl carbamates are insecticides and inhibit *cholinesterase* in animals.

CARCINOGENIC—The ability of a substance or agent to induce malignant tumors (cancer).

CARRIER—An inert liquid, solid, or gas added to an active ingredient to make a pesticide dispense effectively. A carrier is also the material, usually water or oil, used to dilute the formulated product for application.

CASTE—A specialized form within the termite colony that carries out a particular function within the colony. Termite castes include *reproductives*, *workers*, and *soldiers*.

CELLULOSE—A polysaccharide that is the chief part of plant cell walls and the main food source for termites.

CERTIFIED APPLICATORS—Individuals who are certified to use or supervise the use of any restricted-use pesticide covered by their certification.

CHEMICAL NAME—The scientific name of the active ingredient(s) found in the formulated product. This complex name is derived from the chemical structure of the active ingredient.

CHEMICAL CONTROL—Pesticide application to kill pests.

CHEMOSTERILANT—A chemical compound capable of preventing animal reproduction.

CHEMTREC—The Chemical Transportation Emergency Center has a toll-free number (800-424-9300) that provides 24-hour information for chemical emergencies such as a spill, leak, fire, or accident.

CHLORINATED HYDROCARBON—A pesticide containing chlorine, carbon, and hydrogen. Many are persistent in the environment. Examples: chlordane, DDT, methoxychlor. Few are used in structural pest management operations today.

CHOLINESTERASE, ACETYLCHOLINESTERASE—An enzyme in animals that helps regulate nerve impulses. This enzyme is depressed by N-methyl carbamate and organophosphate pesticides.

CHRONIC TOXICITY—The ability of a material to cause injury or illness (beyond 24 hours following exposure) from repeated, prolonged exposure to small amounts. (See also *acute toxicity*.)

COMMERCIAL APPLICATOR—A certified applicator who uses or supervises the use of any pesticide classified for restricted use for any purpose or on any property other than that producing an agricultural commodity.

COMMON NAME—A name given to a pesticide's active ingredient by a recognized committee on pesticide nomenclature. Many pesticides are known by a number of trade or brand names, but each active ingredient has only one recognized common name.

COMMUNITY—The various populations of animal species (or plants) that exist together in an ecosystem. (See also *population* and *ecosystem*.)

CONCENTRATION—Refers to the amount of active ingredient in a given volume or weight of formulated product.

CONTAMINATION—The presence of an unwanted substance (sometimes pesticides) in or on plants, animals, soil, water, air, or structures.

CRAWL SPACE—A shallow space below the living quarters of at least a partially basementless house, normally enclosed by the foundation wall.

CULTURAL CONTROL—A pest control method that includes changing human habits—e.g., sanitation, work practices, cleaning and garbage pickup schedules, etc.

DECONTAMINATE—To remove or break down a pesticidal chemical from a surface or substance.

DEFECT ACTION LEVELS—The maximum levels for defects such as the presence of insect fragments, mold, or rodent hairs in food products allowed by the Food and Drug Administration (FDA).

DEGRADATION—The process by which a chemical compound or pesticide is reduced to simpler compounds by the action of microorganisms, water, air, sunlight, or other agents. Degradation products are usually, but not always, less toxic than the original compound.

DEPOSIT—The amount of pesticide on treated surfaces after application.

DERMAL TOXICITY—The ability of a pesticide to cause acute illness or injury to a human or animal when absorbed through the skin. (See *exposure route*.)

DETOXIFY—To render a pesticide's active ingredient or other poisonous chemical harmless.

DIAGNOSIS—The positive identification of a problem and its cause.

DILUENT—Any liquid, gas, or solid material used to dilute or weaken a concentrated pesticide.

DISINFECTANT—A chemical or other agent that kills or inactivates disease-producing microorganisms. Chemicals used to clean or surface-sterilize inanimate objects.

DOSE, DOSAGE—Quantity, amount, or rate of pesticide applied to a given area or target.

DRIFT—The airborne movement of a pesticide spray or dust beyond the intended target area.

DUCTS—In a house, usually round or rectangular metal pipes for distributing warm air from the heating plant to rooms, or cold air from a conditioning device, or as cold-air returns. May be embedded in or placed beneath concrete slabs. Ducts are also made of asbestos and composition material.

DUST—A finely ground, dry pesticide formulation containing a small amount of active ingredient and a large amount of inert carrier or diluent such as clay or talc.

ECOSYSTEM—The pest management unit. It includes a community (of *populations*) with the necessary physical (*harborage*, moisture, temperature) and biotic (food, hosts) supporting factors that allow an infestation of pests to persist.

ELYTRA—A pair of thickened, leathery, or horny front wings (found in the beetle family).

EMULSIFIABLE CONCENTRATE—A pesticide formulation produced by mixing or suspending the active ingredient (the concentrate) and an emulsifying agent in a suitable carrier. When added to water, a milky emulsion is formed.

EMULSIFYING AGENT (EMULSIFIER)—A chemical that aids in the suspension of one liquid in another that normally would not mix together.

EMULSION—A mixture of two liquids that are not soluble in each other. One is suspended as very small droplets in the other with the aid of an emulsifying agent.

ENCAPSULATED FORMULATION—A pesticide formulation with the active ingredient enclosed in capsules of polyvinyl or other materials; principally used for slow release.

ENDANGERED SPECIES—A plant or animal species whose population is reduced to the extent that it is near extinction and that a federal agency has designated as being in danger of becoming extinct.

ENTRY INTERVAL—See *re-entry interval*.

ENVIRONMENT—All of our physical, chemical, and biological surroundings, such as climate, soil, water, and air, and all species of plants, animals, and microorganisms.

ENVIRONMENTAL PROTECTION AGENCY OR EPA—The federal agency responsible for ensuring the protection of humans and the environment from potentially adverse effects of pesticides.

EPA ESTABLISHMENT NUMBER—A number assigned to each pesticide production plant by the EPA. The number indicates the plant at which the pesticide product was produced and must appear on all labels of that product.

EPA REGISTRATION NUMBER—An identification number assigned to a pesticide product when the product is registered by the EPA for use. The number must appear on all labels for a particular product.

ERADICATION—The complete elimination of a (pest) population from a designated area.

EXPOSURE ROUTE OR COMMON EXPOSURE ROUTE—The manner (dermal, oral, or inhalation/respiratory) by which a pesticide may enter an organism.

FIFRA—The Federal Insecticide, Fungicide, and Rodenticide Act; a federal law and its amendments that control pesticide registration and use.

FLASHING—Strips of aluminum, lead, tin, or copper that are worked into the slates or shingles around dormers, chimneys, and other rising parts of buildings to prevent leaking.

FLOATING SLAB—A type of foundation construction in which the foundation wall and footing are separated from the slab floor by an expansion joint. The slab floor is concrete, while the foundation wall can be a variety of materials, such as solid block, hollow block, or concrete.

FLOW METER—Used to measure the application or delivery rate of a chemical—i.e., the amount of chemical delivered per unit area. Flow meters are useful when *calibrating* large-volume sprayers. These meters can also measure the amount of termiticide injected into each hole for subslab applications.

FLOWABLE—A pesticide formulation in which a very finely ground solid particle is suspended (not dissolved) in a liquid carrier.

FOOTING—A masonry section, usually concrete, in a rectangular form wider than the bottom of the *foundation* wall or *pier* it supports.

FORMULATION—The pesticide product as purchased, containing a mixture of one or more active ingredients, carriers (inert ingredients), and other additives making it easy to store, dilute, and apply.

FOUNDATION—The supporting portion of a structure below the first-floor construction, or below grade, down to and including the *footings*.

FRASS—Solid larval insect excrement; mixed with wood fragments in wood-boring and bark-boring insects.

FRUITING BODY—The part of the fungi from which the reproductive spores are produced (e.g., conks, mushrooms, etc.).

FUMIGANT—A pesticide formulation that volatilizes, forming a toxic vapor or gas that kills in the gaseous state. Usually, it penetrates voids to kill pests.

FUNGICIDE—A chemical used to control fungi.

FUNGUS (plural, fungi)—A group of small, often microscopic, organisms that cause rot, mold, and disease. Fungi need moisture or a damp environment (wood rots require at least 19 percent moisture). Fungi are extremely important in the diet of many insects.

GENERAL-USE (UNCLASSIFIED) PESTICIDE—A pesticide that can be purchased and used by the general public. (See also *restricted-use pesticide*.)

GRANULE—A dry pesticide formulation. The active ingredient is either mixed with or coated onto an inert carrier to form a small, ready-to-use, low-concentrate particle that normally does not present a drift hazard. Pellets differ from granules only in their precise uniformity, larger size, and shape.

GROUNDWATER—Water sources located beneath the soil surface from which spring water, well water, etc., are obtained. (See also *surface water*.)

HARBORAGE—Any place or site that shelters and provides other elements (i.e., food, water) required for survival of a particular organism.

HARDWOOD—Wood from non-evergreen trees such as maple, oak, ash, etc.

HAZARD—See *risk*.

HEARTWOOD—A cylinder of dark-colored, dead wood in the center of the tree that is no longer active in conducting sap or water.

HERBICIDE—A pesticide used to kill plants or inhibit plant growth.

HOST—Any animal or plant on or in which another lives for nourishment, development, or protection.

HYPHA (plural, hyphae)—usually, one of the threadlike structures of a fungus.

INERT INGREDIENT—In a pesticide formulation, an inactive material without pesticidal activity.

INGREDIENT STATEMENT—The portion of the label on a pesticide container that gives the name and amount of each active ingredient and the total amount of inert ingredients in the formulation.

INHALATION—Taking a substance in through the lungs; breathing in. (See *exposure route*.)

INSPECTION—To examine for pests, pest damage, other pest evidence, etc. (See *monitoring*.)

INTEGRATED PEST MANAGEMENT (IPM)—A planned pest control program in which various methods are integrated and used to keep pests from causing economic, health-related, or aesthetic injury. IPM includes reducing pests to a tolerable level. Pesticide application is not the primary control method but is an element of IPM—as are cultural and structural alterations. IPM programs emphasize communication, monitoring, inspection, and evaluation (keeping and using records).

JOIST—One of a series of parallel beams, usually 2 inches in thickness, used to support floor and ceiling loads, and supported in turn by larger beams, girders, bearing walls, or foundation.

LABEL—All printed material attached to or on a pesticide container.

LABELING—The pesticide product label and other accompanying materials that contain directions that pesticide users are legally required to follow.

LARVA (plural, larvae)—An early developmental stage of insects with complete metamorphosis. Insects hatch out of the egg as larvae before becoming *pupae* (resting stage), and then adults.

LC₅₀—Lethal concentration. The concentration of a pesticide, usually in air or water, that kills 50 percent of a test population of animals. LC₅₀ is usually expressed in parts per million (ppm). The lower the LC₅₀ value, the more acutely toxic the chemical.

LD₅₀—Lethal dose. The dose or amount of a pesticide that can kill 50 percent of the test animals when eaten or absorbed through the skin. LD₅₀ is expressed in milligrams of chemical per kilogram of body weight of the test animal (mg/kg). The lower the LD₅₀, the more acutely toxic the pesticide.

LEACHING—The movement of a substance with water downward through soil.

LIGNIN—a complex structural polymer that imparts rigidity to certain plant cell walls, especially walls of wood cells.

MATERIAL SAFETY DATA SHEETS (MSDS)—These data sheets contain specific information on toxicity, first aid, personal protective equipment, storage and handling precautions, spill and leak cleanup and disposal practices, transportation, physical data, and reactivity data. MSDS are available from manufacturers.

MESOTHORAX—The second segment of an insect's *thorax*. One pair of legs and usually one pair of wings are attached.

METAMORPHOSIS—A change in the shape, or form, of an animal. Usually used when referring to insect development.

METATHORAX—The third segment of an insect's *thorax*. One pair of legs and often one pair of wings are attached.

MICROBIAL PESTICIDE—Bacteria, viruses, fungi, and other microorganisms used to control pests. Also called biorationals.

MICROORGANISM—An organism so small it can be seen only with the aid of a microscope.

MODE OF ACTION—The way in which a pesticide exerts a toxic effect on the target plant or animal.

MOISTURE METER—A device used to measure moisture content in wood. A moisture content greater than 20 percent indicates conditions that will lead to decay.

MOLT—Periodic shedding of the outer layer (e.g., an insect's *exoskeleton* is shed periodically).

MONITORING—On-going surveillance. Monitoring includes inspection and record keeping. Monitoring records allows technicians to evaluate pest population suppression, identify infested or non-infested sites, and manage the progress of the management or control program.

MONOLITHIC SLAB—A type of foundation construction in which the foundation footing and the slab floor are formed as one continuous unit. Concrete is the material used in this type of slab foundation.

MUD TUBES—See *shelter tubes*.

MYCELIUM (plural, mycelia)—An aggregation of hyphae of a fungus.

NODE—Nodes are swollen segments found at the narrow connection between the thorax and abdomen of ant species. The nodes may be helpful in identifying ant species—most ant species have one node; others have two.

NON-RESIDUAL PESTICIDE—Pesticides applied to obtain effects only during the time of treatment.

NON-TARGET ORGANISM—Any plant or animal other than the intended target(s) of a pesticide application.

ORAL TOXICITY—The ability of a pesticide to cause injury or acute illness when taken by mouth. One of the common exposure routes.

ORGANOPHOSPHATES—A large group of pesticides that contain the element phosphorus and inhibit *cholinesterase* in animals.

PARASITE—A plant, animal, or microorganism living in, on, or with another living organism for the purpose of obtaining all or part of its food.

PARESTHESIA—A reaction to dermal exposure to some pesticides (especially pyrethroids) with symptoms similar to sunburn sensation of the face and especially the eyelids. Sweating, exposure to sun or heat, and application of water aggravate the disagreeable sensations. This is a temporary effect that dissipates within 24 hours. For first aid, wash with soap and water to remove as much residue as possible, and then apply a vitamin E oil preparation or cream to the affected area. Persons susceptible to paresthesia should choose a pesticide with a different active ingredient and/or formulation.

PATHOGEN—A disease-causing organism.

PERSONAL PROTECTIVE EQUIPMENT (PPE)—Devices and clothing intended to protect a person from exposure to pesticides. Includes such items as long-sleeved shirts, long trousers, coveralls, suitable hats, gloves, shoes, respirators, and other safety items as needed.

PEST MANAGEMENT—The reduction of pest populations to tolerable numbers by changing practices, making habitat or structural alterations, and carefully using pesticides to kill pests only when indicated.

PEST—An undesirable organism (plant, animal, bacterium, etc.); any organism that competes with people for food, feed, or fiber, causes structural damage, is a public health concern, reduces aesthetic qualities, or impedes industrial or recreational activities.

PESTICIDE—A chemical or other agent used to kill, repel, or otherwise control pests or to protect from a pest.

pH—A measure of the acidity/alkalinity of a liquid—acid below pH7; basic or alkaline above pH7 (up to 14).

PHEROMONE—A substance emitted by an animal to influence the behavior of other animals of the same species. Examples are sex pheromones (to attract mates) and aggregation pheromones (to keep members of the same species together in a group). Some pheromones are synthetically produced for use in insect traps.

PHOTODEGRADATION—Breakdown of chemicals by the action of light.

PHYSICAL CONTROL—Altering habitat or changing the infested physical structure—e.g., caulking holes, cracks, tightening around doors, windows, moisture reduction, ventilation, etc.

PHYTOTOXICITY—Injury to plants caused by a chemical or other agent.

PIER—A column of masonry or sometimes wood, usually rectangular in horizontal cross-section, used to support other structural members.

POISON CONTROL CENTER—A local agency, generally a hospital, that has current information on the proper first aid techniques and antidotes for poisoning emergencies. Centers are listed in telephone directories.

POPULATION—Individuals of the same species. The populations in an area make up a community. (See *ecosystem*.)

PRECIPITATE—A solid substance that forms in a liquid and settles to the bottom of a container; a material that no longer remains in suspension.

PREDATOR—An animal that attacks, kills, and feeds on other animals. Examples of predaceous animals are hawks, owls, snakes, many insects, etc.

PRONOTUM—The area just behind an insect's head (i.e., the upper plate of the *prothorax*).

PROPELLANT—The inert ingredient in pressurized products that forces the active ingredient from the container.

PROTHORAX—The first segment of an insect's *thorax*. One pair of legs is attached.

PROTOZOAN—A unicellular animal; termites are dependent on a specific type of protozoan to help them digest *cellulose*.

PUPA (plural, pupae)—The developmental (resting) stage of insects with complete metamorphosis during which major changes from the larval to the adult form occur.

RAFTER—One of a series of structural members of a roof designed to support roof loads. The rafters of a flat roof are sometimes called roof joists.

RATE OF APPLICATION—The amount of pesticide applied to a plant, animal, unit area, or surface; usually measured as per acre, per 1,000 square feet, per linear foot, or per cubic foot.

READY-TO-USE PESTICIDE—A pesticide that is applied directly from its original container consistent with label directions, such as an aerosol insecticide or rodent bait box, which does not require mixing or loading prior to application.

RE-ENTRY INTERVAL—The length of time following an application of a pesticide when entry into the treated area is restricted.

REGISTERED PESTICIDES—Pesticide products that have been registered by the Environmental Protection Agency for the uses listed on the label.

REPELLENT—A compound that keeps insects, rodents, birds, or other pests away from humans, plants, domestic animals, buildings, or other treated areas.

REPRODUCTIVES—The *caste* within the termite colony that is responsible for reproduction and for establishing new termite colonies. Subterranean termite colonies have both primary (winged males and females) and supplementary (wingless [or with short, non-functional wings] males and females) reproductives.

RESIDUAL PESTICIDE—A pesticide that continues to remain effective on a treated surface or area for an extended period following application.

RESIDUE—The pesticide active ingredient or its breakdown product(s) that remain in or on the target after treatment.

RESTRICTED-USE PESTICIDE—A pesticide that can be purchased and used only by certified applicators or persons under their direct supervision. A pesticide classified for restricted use under FIFRA, Section 3(d)(1)(C).

RHIZOMORPH—A thread- or rootlike fungal structure made up of *hyphae*.

RISK—A probability that a given pesticide will have an adverse effect on humans or the environment in a given situation.

RODDING—A method of applying termiticide. Long rods may be used to apply termiticide into the soil next to the foundation wall. Shorter rods are used to inject termiticide into the voids of walls and through concrete slabs.

RODENTICIDE—A pesticide used to control rodents.

RUNOFF—The movement of water and associated materials on the soil surface. Runoff usually proceeds to bodies of surface water.

SAPWOOD—A lighter colored ring of wood surrounding the *heartwood* of the tree that consists of cells that are actively conducting water and sap.

SEASONED—Lumber that has been chemically treated with wood preservatives and prepared for use. (See also *unseasoned*.)

SHEATHING—The structural covering, usually wood boards or plywood, used over studs or rafters of a structure. Structural building board is normally used only as a wall sheathing.

SHELTER TUBES—Tubes constructed by subterranean termites to help them pass over exposed areas and reach new food sources (cellulose). Termites require a constant source of moisture and the shelter tubes enable this by providing a moist environment and allowing them to maintain contact with the soil. The tubes also serve to conceal the termites and protect them from natural enemies (ants). (Also referred to as *mud tubes*.)

SIGNAL WORDS—Required word(s) that appear on every pesticide label to denote the relative toxicity of the product. Signal words are DANGER-POISON, DANGER, WARNING, and CAUTION.

SILL PLATE—A horizontal member anchored on top of a masonry wall.

SITE—Areas of pest infestation. Each site should be treated specifically or individually.

SOFFIT—The underside of an overhanging part or member (especially on the roof) of a building.

SOFTWOOD—Wood from evergreen trees such as pines, firs, and spruces.

SOLDIERS—Refers to the *caste* within a termite colony that is responsible for the defense of the colony.

SOLUTION—A mixture of one or more substances in another substance (usually a liquid) in which all the ingredients are completely dissolved. Example: sugar in water.

SOLVENT—A liquid that will dissolve another substance (solid, liquid, or gas) to form a solution.

SLAB-ON-GROUND—The type of foundation construction in buildings without basements or crawl spaces. The three basic types of slab-on-ground construction are *floating slab*, *monolithic slab*, and *suspended slab* (Figures 4.1-4.3).

SOUNDING—A method of detecting damaged wood by tapping on the wood and listening for a hollow sound, which indicates cavities that are non-visible from the surface.

SPACE SPRAY—A pesticide that is applied as a fine spray or mist to a confined area.

SPOT TREATMENT—Application of a pesticide to limited areas where pests are likely to be found. A method used to avoid contact of pesticides with food, utensils, or people.

SPRINGWOOD—The wood produced early in the season that is of lower density than wood produced later in the season.

STOMACH POISON—A pesticide that must be eaten by an animal to be effective; it will not kill on contact.

SUBFLOOR—Boards of plywood laid on joists, over which a finished floor is laid.

SUMP—A pit, well, or the like in which water or other liquid is collected.

SURFACE WATER—Water on the earth's surface: rivers, lakes, ponds, streams, etc. (See also *groundwater*.)

SUSPENDED SLAB—A type of foundation construction in which the slab floor and the foundation wall are separate units, with the slab floor extending over the top of the foundation wall. The slab floor is concrete; the material used for the foundation wall may vary.

SUSPENSION—Pesticide mixtures consisting of fine particles dispersed or floating in a liquid, usually water or oil. Example: wettable powders in water.

SWARMERS—The winged primary *reproductives* (both male and female) of the termite colony. They leave the colony in swarms, usually in the spring or fall. These swarms are often the first visible indication that a termite infestation is present. (See also *alates*.)

SWARMING—When winged termite primary reproductives leave the colony in great numbers to mate and start a new colony.

TARGET—The plants, animals, structures, areas, or pests at which the pesticide or other control method is directed.

TERMITE SHIELD—A shield, usually of non-corrodible metal, placed in or on a foundation wall, other mass of masonry, or around pipes to prevent the passage of termites.

THORAX—The middle part of an insect's body between the head and the abdomen. It is divided into three segments—the *prothorax*, *mesothorax*, and *metathorax*. A pair of legs is attached to each thoracic region.

THRESHOLD—A level of pest density. The number of pests observed, trapped, counted, etc., that could be tolerated without an economic loss or aesthetic injury. Pest thresholds in structural pest management may be site-specific—for example, different numbers of cockroaches may be tolerated at different sites (e.g., hospitals and garbage rooms). A threshold may be set at zero (e.g., termites in a wooden structure, flies in an operatory).

TOLERABLE LEVELS OF PESTS—The presence of pests at certain levels is tolerable in many situations. Totally eliminating pests in certain areas is sometimes not achievable without major structural alterations, excessive control measures, unacceptable disruption, unacceptable cost, etc. Pest levels that depend on pest observations vary. The tolerable level in some situations will be zero (e.g., termites). Structural pest management programs usually have lower tolerable levels of pests than agricultural programs.

TOXIC—Poisonous to living organisms.

TOXICANT—A poisonous substance such as the active ingredient in a pesticide formulation.

TOXICITY—The ability of a pesticide to cause harmful, acute, delayed, or allergic effects. The degree or extent to which a chemical or substance is poisonous.

TOXIN—A naturally occurring poison produced by plants, animals, or microorganisms. Examples: the poison produced by the black widow spider, the venom produced by poisonous snakes, and the botulism toxin produced by a bacterium.

TRENCHING—A method for applying termiticide to soil. Soil is removed by digging a trench to within about 1 foot above the footing. As the soil is replaced, it is treated with termiticide.

TROPHALLAXIS—A form of communication within the termite colony that involves the mutual exchange of nutrients and the transfer of food between colony members. Trophallaxis permits the efficient use of nutrients within the colony, enhances recognition of colony members, distributes chemicals involved in caste regulation, and transfers cellulose-digesting protozoans.

UNSEASONED—Lumber that has not yet been chemically treated. (See also *seasoned*.)

USE—The performance of pesticide-related activities requiring certification include application, mixing, loading, transport, storage, or handling after the manufacturer's seal is broken; care and maintenance of application and handling equipment; and disposal of pesticides and their containers in accordance with label requirements. Uses not needing certification are long-distance transport, long-term storage, and ultimate disposal.

VAPOR BARRIER—Material used to retard the movement of water vapor into walls or slabs and to prevent condensation in them. Also a covering used over dirt in crawl spaces. Common materials: polyethylene film, asphalt paper.

VAPOR PRESSURE—The property that causes a chemical to evaporate. The higher the vapor pressure, the more volatile the chemical and the easier it will evaporate.

VECTOR—A carrier, an animal (e.g., insect, nematode, mite) that can carry and transmit a pathogen from one host to another.

VERTEBRATE—Animal characterized by a segmented backbone or spinal column.

VIRUS—Ultramicroscopic parasites composed of proteins. Viruses can multiply only in living tissues and cause many animal and plant diseases.

VOLATILITY—The degree to which a substance changes from a liquid or solid state to a gas at ordinary temperatures when exposed to air.

WATER TABLE—The upper level of the water-saturated zone in the ground.

WETTABLE POWDER—A dry pesticide formulation in powder form that forms a suspension when added to water.

WORKERS—The sexually underdeveloped *caste* of the termite colony that is responsible for most of the work of the colony—foraging, feeding, and grooming of the other castes (including the queen), building and repairing the nest, and making the tunnels. They are the most numerous and destructive members of the colony.

ZONE LINES—A symptom of infestation in wood from white rot fungi—thin, dark lines form around the decayed areas.

For the further definition of terms, consult:

Pesticide Applicator Core Training Manual, E-2195, Michigan State University Extension.

The Federal Insecticide, Fungicide, and Rodenticide Act as amended. Public Law 92-516, October 21, 1972, as amended by Public Law 94-140, November 28, 1975, and Public Law 95-396, September 30, 1978.

Federal Register, November 7, 1990, Part II Environmental Protection Agency 40, CFR Part 171, Certification of Pesticide Applicator; Proposed Rule.

Region V Office of the EPA, Chicago, Ill.

Michigan Department of Agriculture State Plan for Commercial and Private Applicators.

Local, state, and national pest control associations.

APPENDIX C

WOOD-BORING INSECTS

Table 1. Characteristics of damage caused by common wood-boring insects

Insect Type	Shape and Size (inches) of Exit/Entry Hole	Wood Type	Age of Wood Attacked*	Appearance of Frass in Tunnels	Reinfests Structural Timber
Ambrosia beetles	Round, 1/50 to 1/8	Softwood and hardwood	New	None present	No
Lyctid beetles	Round, 1/32 to 1/16	Hardwood	New and old	Fine, flourlike, loosely packed	Yes
Bark beetles	Round, 1/16 to 3/32	Bark/ sapwood interface	New	Fine to coarse, bark-colored, tightly packed	No
Anobiid beetles	Round, 1/16 to 1/8	Softwood and hardwood	New and old	Fine powder and pellets, loosely packed; pellets may be absent and frass tightly packed in some hardwoods	Yes
Bostrichid beetles	Round, 3/32 to 9/32	Softwood and hardwood (bamboo)	New	Fine to coarse powder, tightly packed	Rarely
Horntail or wood wasp	Round, 1/6 to 1/4	Softwood	New	Coarse, tightly packed	No
Carpenter bee	Round, 1/2	Softwood	New and old	None present	Yes
Round-headed borer	Round-oval, 1/8 to 3/8	Softwood and hardwood	New	Coarse to fibrous, mostly absent	No
Flat-headed borer	Oval, 1/8 to 1/2	Softwood and hardwood	New	Sawdustlike, tightly packed	No
Old house borer	Oval, 1/4 to 3/8	Softwood	New and old	Very fine powder and tiny pellets, tightly packed	Yes
Round- or flat-headed borer, wood machined after attack	Flat oval, 1/2 or more; or irregular surface groove, 1/8 to 1/2	Softwood and hardwood	New	Absent or sawdustlike, coarse to fibrous; tightly packed	No


* New wood is defined as standing or freshly felled trees and unseasoned lumber. Old wood is seasoned or dried lumber.

Source: M.P. Levy, *A Guide to the Inspection of Existing Homes for Wood-inhabiting Fungi and Insects*, U.S. Department of Housing and Urban Development, Washington, D.C., 1975.

APPENDIX D

STRUCTURAL AND HOUSING TERMS

Diagrams Identifying Structural Members



APPENDIX E

CONVENIENT CONVERSION FACTORS

Multiply	By	To Get
Acres	0.405	Hectares
Acres	4,047.0	Square Meters
Acres	4,840.0	Square Yards
Acres-feet	43,560.0	Square feet
Acre-feet	1,233.49	Cubic Meters
Acre-feet	43,560.0	Cubic Feet
Acre-feet	325,850.58	Gallons
Bushels	0.0461	Cubic yards
Bushels	1.2437	Cubic feet
Bushels	4.0	Pecks
Bushels	32.0	Quarts (dry)
Bushels	35.24	Liters
Bushels	64.0	Pints (dry)
Bushels	2,150.42	Cubic inches
Centimeters	0.3627	Inches
Centimeters	0.01	Meters
Centimeters	10.0	Millimeters
Cubic centimeters	0.0610	Cubic inches
Cubic centimeters	0.03381	Ounces (liquid)
Cubic centimeters	1.0	Milliliters of water
Cubic centimeters	1.0	Grams of water
Cubic feet	0.0283	Cubic meters
Cubic feet	0.0370	Cubic yards
Cubic feet	0.8040	Bushels
Cubic feet	7.4805	Gallons
Cubic feet	25.71	Quarts (dry)
Cubic feet	28.32	Liters
Cubic feet	29.92	Quarts (liquid)
Cubic feet	51.42	Pints (dry)
Cubic feet	59.84	Pints (liquid)
Cubic feet	62.4	Pounds of water
Cubic feet	1,728.0	Cubic inches
Cubic feet	28,317.0	Cubic centimeters
Cubic meters	1.308	Cubic yards
Cubic meters	35.31	Cubic feet
Cubic meters	264.2	Gallons
Cubic meters	1,000.0	Liters
Cubic meters	1,057.0	Quarts (liquid)
Cubic meters	2,113.0	Pints (liquid)
Cubic meters	61,023.0	Cubic inches
Cubic meters	1,000,000.0	Cubic centimeters
Cubic inches	0.000016	Cubic meters
Cubic inches	0.0005	Bushels
Cubic inches	0.0006	Cubic feet
Cubic inches	0.0019	Pecks (dry)

Multiply	By	To Get
Cubic inches	0.0037	Gallons (dry)
Cubic inches	0.0043	Gallons (liquid)
Cubic inches	0.0149	Quarts (dry)
Cubic inches	0.0164	Liters
Cubic inches	0.0173	Quarts (liquid)
Cubic inches	0.0298	Pints (dry)
Cubic inches	0.0346	Pints (liquid)
Cubic inches	0.0361	Pounds of water
Cubic inches	0.5540	Ounces (liquid)
Cubic inches	16.3872	Cubic centimeters
Cubic yards	0.7646	Cubic meters
Cubic yards	21.71	Bushels
Cubic yards	27.0	Cubic feet
Cubic yards	202.0	Gallons (liquid)
Cubic yards	807.9	Quarts (liquid)
Cubic yards	1,616.0	Pints (liquid)
Cubic yards	7,646.0	Liters
Cubic yards	46,656.0	Cubic inches
Cups	0.25	Quarts (liquid)
Cups	0.5	Pints (liquid)
Cups	8.0	Ounces (liquid)
Cups	16.0	Tablespoons
Cups	48.0	Teaspoons
Cups	236.5	Milliliters
Feet	0.3048	Meters
Feet	0.3333	Yards
Feet	12.0	Inches
Feet	30.48	Centimeters
Feet per minute	0.01136	Miles per hour
Feet per minute	0.01667	Feet per second
Feet per minute	0.01829	Kilometers per hour
Feet per minute	0.3048	Meters per minute
Feet per minute	0.3333	Yards per minute
Feet per minute	60.0	Feet per hour
Gallons	0.00378	Cubic meters
Gallons	0.1337	Cubic feet
Gallons	3.785	Liters
Gallons	4.0	Quarts (liquid)
Gallons	8.0	Pints (liquid)
Gallons	8.337	Pounds
Gallons	128.0	Ounces (liquid)
Gallons	231.0	Cubic inches (liquid)
Gallons	269.0	Cubic inches (dry)
Gallons	3,785.0	Cubic centimeters

Multiply	By	To Get
Gallons of water	0.0038	Cubic meters
Gallons of water	0.0049	Cubic yards
Gallons of water	0.1337	Cubic feet
Gallons of water	3.7853	Kilograms
Gallons of water	8.3453	Pounds of water
Gallons of water	3,785.3446	Grams
Grains	0.0648	Grams
Grams	0.001	Kilograms
Grams	0.0022	Pounds
Grams	0.0353	Ounces
Grams	15.53	Grains
Grams	1,000.0	Milligrams
Grams per liter	10.0	Percent
Grams per liter	1,000.0	Parts per million
Hectares	2.47	Acres
Hectares	10,000.0	Square meters
Hectares	11,954.8	Square yards
Hectares	107,593.2	Square feet
Inches	0.0254	Meters
Inches	0.02778	Yards
Inches	0.08333	Feet
Inches	2.54	Centimeters
Kilograms	0.0011	Tons
Kilograms	2.205	Pounds
Kilograms	35.28	Ounces
Kilograms	1,000.0	Grams
Kilometers	0.6214	Miles
Kilometers	1,000.0	Meters
Kilometers	1,093.611	Yards
Kilometers	3,280.833	Feet
Kilometers per hour	0.6214	Miles per hour
Kilometers per hour	16.6667	Meters per minute
Kilometers per hour	18.2268	Yards per minute
Kilometers per hour	54.6806	Feet per minute
Liters	0.001	Cubic meters
Liters	0.0353	Cubic feet
Liters	0.2642	Gallons (liquid)
Liters	1.0	Kilograms of water
Liters	1.057	Quarts (liquid)
Liters	2.113	Pints (liquid)
Liters	33.8143	Ounces
Liters	61.02	Cubic inches
Liters	1,000.0	Cubic centimeters
Liters	1,000.0	Grams of water
Meters	0.001	Kilometers
Meters	1.094	Yards
Meters	3.281	Feet
Meters	39.37	Inches
Meters	100.0	Centimeters
Meters	1,000.0	Millimeters

Multiply	By	To Get
Metric tons	1.1	Tons (U.S.)
Metric tons	1,000.0	Kilograms
Metric tons	2,204.6	Pounds
Metric tons	1,000,000.0	Grams
Miles	1.6093	Kilometers
Miles	1,609.3	Meters
Miles	1,760.0	Yards
Miles	5,280.0	Feet
Miles per hour	1.467	Feet per second
Miles per hour	1.6093	Kilometers/ hour
Miles per hour	26.8217	Meters per minute
Miles per hour	29.3333	Yards per minute
Miles per hour	88.0	Feet per minute
Miles per minute	26.82	Meters per second
Miles per minute	29.333	Yards per second
Miles per minute	88.0	Feet per second
Milliliters	0.00105	Quarts (liquid)
Milliliters	0.0021	Pints (liquid)
Milliliters	0.0042	Cups (liquid)
Milliliters	0.0338	Ounces (liquid)
Milliliters	0.0676	Tablespoons
Milliliters	0.2029	Teaspoons
Milliliters	1.0	Cubic centimeters of water
Milliliters	1.0	Grams of water
Ounces (liquid)	0.00781	Gallons
Ounces (liquid)	0.03125	Quarts (liquid)
Ounces (liquid)	0.0625	Pints (liquid)
Ounces (dry)	0.0625	Pounds
Ounces (liquid)	0.125	Cups (liquid)
Ounces (liquid)	1.805	Cubic inches
Ounces (liquid)	2.0	Tablespoons
Ounces (liquid)	6.0	Teaspoons
Ounces (dry)	28.3495	Grams
Ounces (liquid)	29.573	Milliliters
Ounces (dry)	437.5	Grains
Parts / million (PPM)	0.0001	Percent
Parts per million	0.001	Liters/cubic meter
Parts per million	0.001	Grams per liter
Parts per million	0.001	Milliliters per liter
Parts per million	0.013	Ounces per 100 gallons of water
Parts per million	0.0584	Grains per US gallon
Parts per million	0.3295	Gallons per acre-foot of water
Parts per million	1.0	Milligrams/ liter
Parts per million	1.0	Milligrams per kilogram
Parts per million	1.0	Milliliters per cubic meter

Multiply	By	To Get
Parts per million	2.7181	Pounds per acre-foot of water
Parts per million	8.345	Pounds per million gallons of water
Pecks	0.25	Bushels
Pecks	8.0	Quarts (dry)
Pecks	16.0	Pints (dry)
Pecks	537.605	Cubic inches
Percent (%)	1.33	Ounces (dry) per gallon of water
Percent	8.34	Pounds per 100 gallons of water
Percent	10.00	Grams per kilogram
Percent	10.00	Grams per liter
Percent	10,000.00	Parts per million
Pints (dry)	0.0156	Bushels
Pints (dry)	0.0625	Pecks
Pints (liquid)	0.125	Gallons
Pints (liquid)	0.4735	Liters
Pints (liquid)	0.5	Quarts (liquid)
Pints (dry)	0.5	Quarts (dry)
Pints (liquid)	2.0	Cups
Pints (liquid)	16.0	Ounces (liquid)
Pints (liquid)	28.875	Cubic inches (liquid)
Pints (dry)	33.6003	Cubic inches (dry)
Pounds	0.0005	Tons
Pounds	0.4535	Kilograms
Pounds	16.0	Ounces
Pounds	453.5924	Grams
Pounds	7,000.0	Grains
Pounds of water	0.0160	Cubic feet
Pounds of water	0.1198	Gallons
Pounds of water	0.4536	Liters
Pounds of water	27.693	Cubic inches
Quarts (liquid)	0.00094	Cubic meters
Quarts (liquid)	0.0012	Cubic yards
Quarts (dry)	0.03125	Bushels
Quarts (liquid)	0.0334	Cubic feet (liquid)
Quarts (dry)	0.0389	Cubic feet (dry)
Quarts (dry)	0.125	Pecks
Quarts (liquid)	0.25	Gallons (liquid)
Quarts (liquid)	0.9463	Liters
Quarts (liquid)	2.0	Pints (liquid)
Quarts (dry)	2.0	Pints (dry)
Quarts (liquid)	2.0868	Pounds of water
Quarts (liquid)	4.0	Cups
Quarts (liquid)	32.0	Ounces (liquid)
Quarts (liquid)	57.75	Cubic inches (liquid)
Quarts (dry)	67.20	Cubic inches (dry)

Multiply	By	To Get
Square feet	0.000009	Hectares
Square feet	0.000023	Acres
Square feet	0.0929	Square meters
Square feet	0.1111	Square yards
Square feet	144.0	Square inches
Square inches	0.00064	Square meters
Square inches	0.00077	Square yards
Square inches	0.00694	Square feet
Sq. kilometers	0.3861	Square miles
Sq. kilometers	100.0	Hectares
Sq. kilometers	247.104	Acres
Sq. kilometers	1,000,000.0	Square meters
Sq. kilometers	1,195,982.7	Square yards
Sq. kilometers	10,763,865.0	Square feet
Square meters	0.0001	Hectares
Square meters	1.308	Square yards
Square meters	10.765	Square yards
Square meters	1,549.9669	Square feet
Square miles	2.5899	Square kilometers
Square miles	258.99	Hectares
Square miles	640.0	Acres
Square miles	2,589,735.5	Square meters
Square miles	3,097,600.0	Square yards
Square miles	27,878,400.0	Square feet
Square yards	0.00008	Hectares
Square yards	0.00021	Acres
Square yards	0.8361	Square meters
Square yards	9.0	Square feet
Square yards	1,296.0	Square inches
Tablespoons	0.0625	Cups
Tablespoons	0.5	Ounces
Tablespoons	3.0	Teaspoons
Tablespoons	15.0	Milliliters
Teaspoons	0.0208	Cups
Teaspoons	0.1667	Ounces
Teaspoons	0.3333	Tablespoons
Teaspoons	5.0	Milliliters
Tons	0.907	Metric ton
Tons	907.1849	Kilograms
Tons	2,000.0	Pounds
Tons	32,000.0	Ounces
Yards	0.000568	Miles
Yards	0.9144	Meters
Yards	3.0	Feet
Yards	36.0	Inches

APPENDIX F

BIBLIOGRAPHY

Wood-destroying and General Pest Control References.

- Bennett, G.W., J.M. Owens and R.M. Corrigan. 1997. *Truman's Scientific Guide to Pest Control Operations* (5th ed.). Purdue University/Advanstar Communications, Cleveland, Ohio.
- Cutten, G.M. 1988. *Termite Control in Ontario*. Ministry of the Environment, Ottawa, Ontario.
- Koehler, P.G., and W.H. Kern, Jr. 1994. *General Household Pest Control, Applicator Training Manual*. University of Florida, Florida Cooperative Extension Service.
- Levy, M.P. 1975. *A Guide to the Inspection of Existing Homes for Wood-inhabiting Fungi and Insects*. U.S. Department of Agriculture Forest Service and the Department of Housing and Urban Development (IAA-25-75).
- Mallis, A. 1997. *1997 Handbook of Pest Control*. Mallis Handbook & Technical Training Co., Cleveland, Ohio.
- Moore, H. 1979. *Wood-inhabiting Insects in Houses: Their Identification, Biology, Prevention and Control*. U.S. Department of Agriculture Forest Service and the Department of Housing and Urban Development (IAA-25-75).
- New York State Cooperative Extension. 1987. *Preservation and Treatment of Lumber and Wood Products*. Pesticide Applicator Training Manual, Category 7. New York State College of Agriculture and Life Sciences, Cornell University, Ithaca, N.Y.
- Oklahoma Cooperative Extension Service. 1998. *Structural Pest Control*. Oklahoma State University.
- Sanders, D. 1987. *Termite Pest Control, Including Other Wood-damaging Pests*. Manual 96. University Extension, University of Missouri, Columbia.
- Smith, E.H., and R.C. Whitman. 1996. *NPCA Field Guide to Structural Pests*. National Pest Control Association, Dunn Loring, Virginia.
- Smith, J.A. and N.R. Ehmann. *Pest Control Library, Vol. IX: Wood-destroying Organisms (Other than Termites)*. Van Waters & Rogers, Inc., San Jose, California.
- Texas Agricultural Extension Service. 1999. *Control of Termites and Other Wood Pests*. B-5075. The Texas A&M University System.
- Verrall, A.F., and T.L. Amburgey. 1979. *Prevention and Control of Decay in Homes*. U.S. Department of Agriculture Forest Service and the Department of Housing and Urban Development (IAA-25-75).
- Wixted, D., R. Flashinski, P. Pellitteri, and S. Craven. 1997. *Pest Management Principles for the Commercial Applicator: Termite Control* (2nd ed.). University of Wisconsin Extension.
- Wood, E., and L. Pinto. 1992. *Urban Integrated Pest Management: A Guide for Commercial Applicators*. U.S. Environmental Protection Agency (735-B-92-001), DUAL & Associates, Arlington, Virginia.

Selected Subject References (subjects are in bold print).

- Bennett, G.W., and J.M. Owens (eds). 1986. *Advances in Urban **Pest Management***. Van Nostrand Reinhold Company, New York.
- Furman, D.P., and E.P. Catts. 1982. *Manual of **Medical Entomology*** (4th ed.). Cambridge University Press.
- National Pest Management Association. 1982. *Encyclopedia of **Structural Pest Control*** (7 volumes). Dunn Loring, Virginia.
- National Pest Management Association. ***Pest Control Publications***. Publications Resource Center, 8100 Oak St., Dunn Loring, Virginia 22027; phone (703) 573-8330; www.pestworld.org.
- Riergart J.R., and J.R. Roberts. 1999. *Recognition and Management of **Pesticide Poisonings*** (fifth edition). U.S. Environmental Protection Agency, Office of Prevention, Pesticides, and Toxic Substances.
- White, R.E. 1983. *A Field Guide to the **Beetles***. Houghton Mifflin Co., Boston.

Trade Magazines.

- Pest Control*. P.O. Box 6215, Duluth, MN 55806-9915.
- Pest Control Technology*. P.O. Box 5817, Cleveland, OH 44101-9599.
- Pest Management*. National Pest Management Association, 8100 Oak St., Dunn Loring, VA 22027.

Trade Newsletter for Pest Control Technicians.

- Techletter*. Pinto and Associates, Inc., 29839 Oak Road, Mechanicsville, MD 20659-2201; phone (301) 884-3020.



PESTICIDE EMERGENCY INFORMATION

For any type of an emergency involving a pesticide, immediately contact the following emergency information centers for assistance.

Current as of August 2000



Human Pesticide Poisoning

M I C H I G A N P O I S O N C O N T R O L S Y S T E M

From anywhere in Michigan, call

1 - 8 0 0 - P O I S O N 1
1 - 8 0 0 - 7 6 4 - 7 6 6 1

Special Pesticide Emergencies

Animal Poisoning

Your veterinarian:

Phone No.

or

Animal Health Diagnostic Laboratory (Toxicology) Michigan State University: (517) 355-0281

Phone No.

and

Fire Marshal Division, Michigan State Police: **M - F: 8 - 12, 1 - 5** (517) 322-1924

* Telephone Number Operated 24 Hours

Pesticide Fire

Local fire department:

Traffic Accident

Local police department or sheriff's department:

Phone No.

and

Operations Division, Michigan State Police: *(517) 336-6605

Environmental Pollution

Pollution Emergency Alerting System (PEAS), Michigan Department of Environmental Quality:

District MDEQ Office Phone No.

and

For environmental emergencies:

* 1-800-292-4706 also

* 1-800-405-0101 Michigan Department of Agriculture Spill Response

Pesticide Disposal Information

Michigan Department of Environmental Quality, Waste Management Division.

Monday - Friday: 8 a.m.-5 p.m.
(517) 373-2730

National Pesticide Telecommunications Network

Provides advice on recognizing and managing pesticide poisoning, toxicology, general pesticide information and emergency response assistance. Funded by EPA, based at Oregon State University

7 days a week; excluding holidays
6:30 a.m. - 4:30 p.m. Pacific Time Zone
1-800-858-7378
FAX: 1-541-737-0761